


C C



Interior								
Audio	Climate	Navigation	Phase	Effects		Touchscreen		
		Radio S	ettings					
Station presets	Set your state  AM Freq.  1 92.5  2 93.1  3 93.9  4 100.5  5 107.9	ion presets M1 O FM2 Name KTXL KRCA KTAR KWOW KOLT	Zip Code 9 Stations for 92.5 93.1 94.5 100.5 106.5	stations in your person of the state of the		a <u>(RESET)</u>		
Weather interrupt	to receive we	change channels eather alert	<< Copy ✓ Yes					
Traffic interrupt	messages Automatically to receive tro messages	change channels offic alert	☑ Yes					
Standby EBS	broadcast me	or for emergency essages (EBS) and turn on radio	✓ Yes			·		
Scan pause	How long to station is fou	pause when a und when scanning	₪  Short	1 Long	sec			
		General Audio	Settings					
Speed volume control Volume on phone	volume based Automatically audio volume	adjusts audio d on vehicle speed change to this when phone en using the phon	☐ Disable	Louder e feature Louder		RESET		
Startup options	when starting for more tha			e feature        5   High	0			
	source when	select audio starting car after ore than 4 hours	O AM @	e feature DFM1 OFM 2 O3 O	_			
CD Settings								
Label CDs	Uses CDNOW label your co	database to or CDs and songs	Use CDNC	W				
MP3 Settings								
Move MP3 files to car	Move MP3 fill computer to	es from your the car				Browse		

FIG. 3

Audio		l					
	Climate	Navigation	Phase	Effects	Touchscreen		
		<del></del>		Liteta	1 Touchscreen 1		
Personal Clir	nate Settings	Driver: John	•				
Temperature	Automatically select this temperature when this driver starts the car	Cool	72F Warm		RESET		
Humidity	Automatically select this humidity when this driver starts the car	Dry	Humid				
Seat warmer	Temperature when seat warmer is enabled	<b>■</b>    Warm	99F Hot				
Comfort index	How agressive the AUTO climate control responds to adjust temperature and humidity	Gentle A	gressive				
General Climate Settings							
<b>1</b>					RESET		
Auto fan speed	Tailor fan speed when climate control is in AUTO mode	Softer	4 Harder				
InitialTemp	Automatically heat or cool car's interior at preset time of day  Temperature is maintained for 30 minutes unless car is started.  Feature is disabled if car is occupied or	Morning Time: 6:00 A Temp: Cool  Evening Time: 5:30 P Temp: Cool	Warm	₩eek day only 72 F Week day only 72 F			

FIG. 4




FIG. 5